

Satisfyer Pro+ G-Spot Rabbit Generation 2

User manual · G-spot vibrator with air pulse clitoral stimulation and LCD display

Please read the entire manual, including the safety information, before first use and keep it for future reference.

Description

The Satisfyer Pro+ G-Spot Rabbit Generation 2 combines two kinds of stimulation: a curved vibrating shaft for the G-spot and a clitoral attachment with Air Pulse technology. Each function has its own motor and is controlled separately. The LCD display on the handle shows the air pulse level (top number), the selected vibration programme (bottom number) and the battery status.

Charging

1. Fully charge the toy before first use.
2. Plug a USB-C cable into the charging port on the handle and connect the other end to a USB adapter or computer. The port must be clean and dry.
3. The battery symbol on the display flashes while charging and stays lit when fully charged (100%).
4. Charging takes approx. 3 hours; one charge lasts approx. 60 minutes of use.

Do not use the toy while it is charging.

Operation

Air pulse on / off	press and hold the air pulse button for approx. 2 seconds
Air pulse level	press the same button briefly to switch between 11 levels (1-11, top number on the display)
Vibration on / off	press and hold the button with the “~” symbol for approx. 2 seconds
Vibration programme	press the same button briefly to switch between 12 programmes (1-12, bottom number on the display)

Air pulse and vibration can be used separately or at the same time.

Use

- Apply plenty of water-based lubricant. Silicone-based lubricants, oils and creams may damage the surface of the toy.
- Insert the shaft so that the curved tip points towards the front wall of the vagina (G-spot) and the attachment rests on the clitoris.
- Start at the lowest level and increase the intensity gradually.
- The toy is waterproof (IPX7) and can be used in the shower or bath.

Cleaning and storage

- Disconnect the charging cable before cleaning.
- Clean the toy before and after each use with warm water and mild soap or a toy cleaner. Clean the inside of the clitoral attachment as well, for example with a cotton bud.
- Do not use products containing alcohol, petrol or acetone.
- Dry with a soft, lint-free cloth.
- Store in a dry, dust-free place away from direct sunlight and high temperatures, separately from other toys.

Safety information

- Remove piercings or jewellery in the genital area before use.
- Do not use on irritated or damaged skin. Stop using the toy if you experience pain or feel unwell.
- Do not use the toy if it is unusually hot, damaged, deformed or discoloured.
- Do not apply the attachment to the same spot for more than 15 minutes at a time.
- This toy is not a medical device. Keep it out of the reach of children.
- If you have a pacemaker or another implant, consult your doctor before use.
- After moving the toy from a cold to a warm environment, let it reach room temperature before charging.
- Do not throw into fire or expose to high temperatures.

Specifications

Material	silicone, ABS
Battery	Li-Ion 3.7 V, 700 mAh
Charging voltage / current	5 V / max. 500 mA
Interface	USB-C
Charging time	approx. 3 h
Operating time	approx. 60 min
Waterproof	IPX7
Storage temperature	-5 °C to +60 °C

Disposal

This product contains a rechargeable battery – do not dispose of it with household waste. Take it to a collection point for electronic waste.

Manufacturer: Satisfyer GmbH, Am Lenkwerk 3, 33615 Bielefeld, Germany. Based on the manufacturer's official manual. Retailer: www.intimity.cz